JK4 Installation Guide

(2) 7″ rear bolts

(2) 5.5″ center bolts

(2) 7.25″ front bolts

Metal/rubber washers

Mounts to existing factory bolt-on locations. Removable in 5-10 minutes.

Unzip roll bar cover to install power cables

(2) 2" alignment clamps

(2) 1.5" alignment clamps

(2) 40 Amp fuses

Black wire is ground

100 Amp circuit breaker

Battery connection

Power distribution block

Pass through factory rubber grommet on passenger side.

Remove battery for easier access to rubber grommet in firewall.